



- | | | | | | |
|----|-------------------------------|----|--------------------------------------|----|---------------------------|
| 1 | Retaining Clip | 22 | kick lever | 42 | handle cap |
| 2 | rear drag key washer | 23 | bail arm side cover | 43 | Ratchet |
| 3 | rear drag eared washer | 24 | side cover screw | 44 | anti-reverse cam |
| 4 | rear drag washer | 25 | line slider fixed screw | 45 | anti-reverse switch |
| 5 | spool | 26 | bail arm | 46 | anti-reverse switch screw |
| 6 | spool click washer | 27 | screw | 47 | anti-reverse spring |
| 7 | spool click washer spring | 28 | line roller bushing | 48 | body bushing |
| 8 | spool click washer screw | 29 | line roller washer | 49 | drive gear |
| 9 | drag knob assembly | 30 | line roller collar | 50 | drive gear washer |
| 10 | spool assembly | 31 | line roller | 51 | body cover bushing |
| 11 | spool click gear fixed washer | 32 | bail wire assembly | 52 | body cover |
| 12 | spool click gear | 33 | rotor washer | 53 | body cover screw |
| 13 | spool click gear washer | 34 | silent spring | 54 | handle |
| 14 | pinion gear screw | 35 | silent spring bushing | 55 | oscillating gear |
| 15 | rotor nut washer | 36 | pinion gear ball bearing fixed screw | 56 | oscillating gear screw |
| 16 | pinion gear screw fixed screw | 37 | main shaft | 57 | oscillating slider |
| 17 | bail holder side cover | 38 | pinion gear ball bearing | 58 | oscillating slider screw |
| 18 | rotor | 39 | pinion gear | 59 | body |
| 19 | bail trip shaft | 40 | anti-reverse pawl screw | 60 | slider fixed washer |
| 20 | spring fixed plate | 41 | anti-reverse pawl | 61 | slider fixed washer screw |
| 21 | trip shaft spring | | | | |